

FIB-SEM Auriga: FIB gun heating

When the FIB emission is below 2 uA the filament has to be heated.

Written By: José Maria Mateos Melero

FIB Control
FIB Shape Mill Batch GIS Align Options
Gun State, Emission current, Source Lifetime Off Gun is ON
0.1 µA 2056.68 µAh Reset
Unblank FIB BLANKED
Gun Valve Gun Valve is Open Close FIB Gun Pressure = 1.62e-009 mbar Aperture Status Initialise Idle FIB EHT = 30.00 kV FIB EHT Target = 30.00 kV
FIB Extr.Target = -7.83 kV
FIB Suppressor Target = -2000 V
FIB Emission Target = 2.0 µA
Regulate FIB Auto Heating Heating.

This document was generated on 2023-03-31 05:14:12 AM (MST).

Step 1 — Preparation

FIB Control FIB Shape MB Batch GIS Align Options Gun State, Emistion curret, Source Lifetime Otto Out Determine Out File Cont File Determine File Determine F	Fill Construct Image: Construct Image: Construct Construct Construct Image: Construct Construct Construct Image: Construct Co	FIB Filement Heating FIB Shape MM Bach, GIS, Algo Options FIB Filement Heating FIB Shape MM Bach, GIS, Algo Options FIB Filement Heating FIB Shape MM Bach, GIS, Algo Options FIB Filement Status FIB Filement Status FiB Status FIB Filement Status Status FIB Filement Stat
---	---	---

- Turn on FIB gun. [show button in image with colour].
- Blank beam (if not blanked). [show button in image with colour]
- If emission is below 2uA, turn regulate off.
- Set FIB Suppressor Target to -200 V and FIB Extractor Target to -9 kV.
- Open FIB Filament Heating window. [now switch to new step].


Step 2 — FIB gun heating process

FIB Filament Heating
FIB Fil Current = 0 µA
FIB Fil Voltage = 0.0 V
FIB Min. Autoheat Current = 2.000 A
Filament Status
FIB Fil I Target = 3.600 A
FIB Auto Heating Limit = 3.700 A

- Set FIB Fil I Target to 3.600 A.
- Press "Filament On".
- Watch FIB Emission current and wait until it reaches 50.0 uA. [Show in the image where to watch with a colored square]
- Immediately after reaching 50 μA, press "Filament Off".
- In case the FIB Emission current does not reach 50 μA, increase the FIB Fil ITarget value to 3.700 A.

This document was generated on 2023-03-31 05:14:12 AM (MST).

Step 3 — Adjusting FIB Extraction Target



- Lower the FIB Extr. Target by clicking on the right arrow of the slider once per 2 seconds until the the Emission current reaches 10 μA.
- (i) It needs several clicks until a change in the Emission current appears. Be patient and keep clicking slowly!
- at 10 uA wait 5min.
- Wait 1 min and lower to 5 uA.
- Wait 1 min and lower to 4 uA.
- Wait 1 min and lower to 3 uA.
- Wait 1 min and lower to 2uA.
- Wait 1 min and turn regulate on again.

This document was generated on 2023-03-31 05:14:12 AM (MST).